

NMK32203 - Microcontroller

Note20241017 This page is being updated - work in progress...

This course is *Microcontroller*, offered by the Faculty of Electronics Engineering & Technology.

Announcements

[20241017] Updating this for 202425s1 Academic Session.

Lecture Slides

- Lecture 1 - [Overview](#)
- Lecture 2 - [Architecture](#)
- Lecture 3 - [C for 8051](#)
- Lecture 4 - [8051 I/O](#)

Codes (discussed in class)

Introduction to using 'library' code. Single header include file(s) meant for single source compilation. These are meant to be compiled using Keil 8051 compiler.

Library: Serial (UART)

[uart.h](#)

```
#ifndef __MY1UART_H__
#define __MY1UART_H__

/* note: this is NOT compatible with keil's printf */
void uart_init(void) {
    SCON = 0x50;
    TMOD &= 0x0F;
    TMOD |= 0x20;
    TH1 = 253;
    TR1 = 1;
}

void uart_send(unsigned char sdat) {
    SBUF = sdat;
    while (TI==0);
    TI = 0;
}
```

```
}

unsigned char uart_read(void) {
    unsigned char rdat;
    while (RI==0);
    rdat = SBUF;
    RI = 0;
    return rdat;
}

void uart_puts(char* text) {
    while (*text) {
        uart_send(*text);
        text++;
    }
}

#endif /* __MY1UART_H__ */
```

Library: Text LCD

[tlcd.h](#)

```
#ifndef __MY1TLCD_H__
#define __MY1TLCD_H__

#define LCD_DATA P2
sbit LCD_RS = P0^7;
sbit LCD_RW = P0^6;
sbit LCD_EN = P0^5;

void tlcd_delay(unsigned char step) {
    unsigned int loop;
    do {
        loop = 1000; while (--loop);
    } while (--step);
}

void tlcd_write(unsigned char cdat) {
    LCD_RS = 1;
    LCD_RW = 0;
    LCD_DATA = cdat;
    LCD_EN = 1;
    LCD_EN = 0;
    tlcd_delay(1);
}

void tlcd_cmd(unsigned char ccmd) {
```

```

    LCD_RS = 0;
    LCD_RW = 0;
    LCD_DATA = ccmd;
    LCD_EN = 1;
    LCD_EN = 0;
    tlcd_delay(2);
}

void tlcd_init(void) {
    tlcd_cmd(0x38); /* 8 bit mode, 1/16 duty, 5x8 font */
    tlcd_cmd(0x38);
    tlcd_cmd(0x38);
    tlcd_cmd(0x06); /* display off */
    tlcd_cmd(0x0c); /* display on, blink cursor on */
    tlcd_cmd(0x01); /* clear display */
}

void tlcd_puts(char* text) {
    while (*text) {
        tlcd_write(*text);
        text++;
    }
}

#endif /* __MY1TLCD_H__ */

```

Library: Timer

timer.h

```

#ifndef __MY1TIMER_H__
#define __MY1TIMER_H__

// useful macro!
#define timer0_init() { TMOD &= 0xF0; TMOD |= 0x01; }
#define timer0_prep(hi,lo) { TH0 = hi; TL0 = lo; }
#define timer0_stop() { TR0 = 0; TF0 = 0; }
#define timer0_exec() { TR0 = 1; }
#define timer0_flag() { timer0_exec(); while (!TF0); }
#define timer0_wait(hi,lo) { timer0_prep(hi,lo); timer0_flag(); timer0_stop(); }
#define timer0_null() { TH0 = 0; TL0 = 0; }
#define timer0_read() ((unsigned int)TH0<<8)|TL0

void timer0_delaysms(unsigned int step) {
    do {
        timer0_wait(0xfc,0x66); // 1 ms delay
    } while (--step);
}

```

```
}  
  
#endif /* __MY1TIMER_H__ */
```

Library: Utilities (str-int conversions)

[utils.h](#)

```
#ifndef __MY1UTILS_H__  
#define __MY1UTILS_H__  
  
unsigned char uint8_2cstr(char* cstr, unsigned char that) {  
    unsigned char size, temp;  
    size = 0;  
    temp = that/100;  
    if (temp) {  
        that %= 100;  
        cstr[size++] = temp + 0x30;  
    }  
    temp = that/10;  
    if (temp) {  
        that %= 10;  
        cstr[size++] = temp + 0x30;  
    } else if (size)  
        cstr[size++] = 0x30;  
    cstr[size++] = that + 0x30;  
    cstr[size] = 0x0;  
    return size;  
}  
  
unsigned char int8_2cstr(char* cstr, signed char that) {  
    if (that<0) {  
        that = -that;  
        *cstr = '-';  
        cstr++;  
    }  
    return uint8_2cstr(cstr, (unsigned char)that);  
}  
  
unsigned char uint16_2cstr(char* cstr, unsigned int that) {  
    unsigned char size, temp;  
    unsigned int idiv;  
    size = 0; idiv = 10000;  
    while (idiv>=10) {  
        temp = (unsigned char)(that/idiv);  
        if (temp) {  
            that %= idiv;  
            cstr[size++] = temp + 0x30;  
        }  
        idiv /= 10;  
    }  
    temp = (unsigned char)that;  
    if (temp) {  
        cstr[size++] = temp + 0x30;  
    }  
    cstr[size] = 0x0;  
    return size;  
}
```

```
        } else if (size)
            cstr[size++] = 0x30;
        idiv /= 10;
    }
    cstr[size++] = that + 0x30;
    cstr[size] = 0x0;
    return size;
}

unsigned char int16_2cstr(char* cstr, int that) {
    if (that < 0) {
        that = -that;
        *cstr = '-';
        cstr++;
    }
    return uint16_2cstr(cstr, (unsigned int)that);
}

unsigned char cstr_2uint8(char* pstr, unsigned char* pval) {
    unsigned char loop;
    *pval = 0; loop = 0;
    while (pstr[loop]) {
        if (pstr[loop] < 0x30 || pstr[loop] > 0x39) {
            loop = 0;
            break;
        }
        *pval = (*pval * 10) + (pstr[loop] - 0x30);
        loop++;
    }
    return loop;
}

unsigned char cstr_2uint16(char* pstr, unsigned int* pval) {
    unsigned char loop;
    *pval = 0; loop = 0;
    while (pstr[loop]) {
        if (pstr[loop] < 0x30 || pstr[loop] > 0x39) {
            loop = 0;
            break;
        }
        *pval = (*pval * 10) + (pstr[loop] - 0x30);
        loop++;
    }
    return loop;
}

unsigned char cstr_2int16(char* pstr, int* pval) {
    unsigned char loop, skip;
    skip = (pstr[0] == '-') ? 1 : 0;
    loop = cstr_2uint16(&pstr[skip], (unsigned int*)pval);
    if (skip) *pval = -(*pval);
}
```

```
        return loop;  
    }  
  
#endif /** __MYUTILS_H__ */
```

From:
<http://azman.unimap.edu.my/dokuwiki/> - **Azman @UniMAP**

Permanent link:
<http://azman.unimap.edu.my/dokuwiki/doku.php?id=archive:nmk322&rev=1730694473>

Last update: **2024/11/04 12:27**

