

8051 Codes

Example codes (in C) for the classical Intel-8051 (mcu51) microcontroller core. Using my1code51 library. Tested using sdcc open source compiler and stc12 device.

Codes for NMK322

Testing IR module and HC-SR04 ultrasonic sensor module.

test0.c

```

/*-----*/
-----*/
#include "uart.h"
#include "timer.h"
#define FPSIZE 2
#include "utils_float.h"
#define _LCD_4BIT_INTERFACE_
/** DB4-DB7 => P0 (UPPER NIBBLE) */
/** E => P0.2 ; NEEDS -ve EDGE */
/** R/W => P0.1 ; 0=WR 1=RD */
/** RS => P0.0 ; 0=CMD 1=DAT */
#include "textlcd.h"
/*-----*/
-----*/
/**
 * Testing IR module and HC-SR04 ultrasonic sensor module
 * - display on both uart and lcd
 */
/*-----*/
-----*/
MY1SBIT(IRMOD, PIN10);
MY1SBIT(TRIG, PIN16);
MY1SBIT(ECHO, PIN17);
/*-----*/
-----*/
MY1SBIT(TEST_IR, PIN14);
MY1SBIT(TEST_HC, PIN15);
/*-----*/
-----*/
#define FLAG_IR 0x01
#define FLAG_HC 0x02
/*-----*/
-----*/
void main(void) {
    unsigned char wait;

```

```
unsigned int tval, loop, flag;
float fval, dist;
char buff[16];
uart_init();
uart_puts("\r\nTESTING NMK322 STUFFS\r\n");
lcd_init();
lcd_goto_line1();
lcd_puts("TESTKIT 4 NMK322");
timer_init();
flag = 0;
while (1) {
    if (TEST_IR==0) {
        if ((flag&FLAG_IR)==0) {
            lcd_goto_line1();
            lcd_puts("TEST 4 IR MODULE");
            uart_puts("\r\nTESTING IR MODULE\r\n");
            flag = FLAG_IR;
        }
        lcd_goto_line2();
        lcd_puts("                ");
        lcd_goto_line2();
        lcd_puts("Waiting... ");
        uart_puts("\r\nWaiting... ");
        while (IRMOD); // outputs logic low when obstacle detected
        lcd_puts("|*");
        uart_puts("|*");
        while (!IRMOD);
        lcd_puts("|");
        uart_puts("| \r\n");
        for (loop=65000; loop; loop--);
    }
    if (TEST_HC==0) {
        if ((flag&FLAG_HC)==0) {
            lcd_goto_line1();
            lcd_puts("TEST HC-SR04 MOD");
            uart_puts("\r\nTESTING HC-SR04 MODULE\r\n");
            flag = FLAG_HC;
        }
        lcd_goto_line2();
        lcd_puts("                ");
        lcd_goto_line2();
        timer_prep(0);
        TRIG = 1;
        for (wait=10; wait; wait--); // around 10us?
        TRIG = 0;
        while (!ECHO); timer_exec();
        while (ECHO); timer_stop();
        tval = ((unsigned int)TH0<<8)|TL0;
        fval = (float)tval * 1.085; // in us
        dist = fval / 58.0; // in cm
    }
}
```



```
#include "servo.h"
/*-----*/
-----*/
MY1SBIT(G0000,PIN15);
MY1SBIT(G01MS,PIN16);
MY1SBIT(G02MS,PIN17);
/*-----*/
-----*/
#define BUFFSIZE 128
/*-----*/
-----*/
__xdata char buff[BUFFSIZE];
/*-----*/
-----*/
void main(void) {
    unsigned char curr, test;
    G0000 = 1; G01MS = 1; G02MS = 1;
    timer_init();
    servo_init();
    lcd_init();
    lcd_goto_line1();
    lcd_puts("NMK322 SV/LCD/BT");
    uart_init();
    uart_puts("NMK322 SV/LCD/BT\r\n\r\n");
    hc06_init();
    curr = 3;
    do {
        uart_puts("-- Sending AT... ");
        hc06_find();
        if (hc06_wait_ok()==HC06_OK) {
            uart_puts("OK.\r\n");
            uart_puts("\r\nSet default name & pin\r\n");
            uart_puts("-- Set Name (");
            uart_puts(BTNAME);
            uart_puts("): ");
            hc06_setname(buff,BUFFSIZE);
            uart_puts(buff);
            uart_puts("\r\n");
            timer_delay1s(test,1);
            /* set pass */
            uart_puts("-- Set Pin (");
            uart_puts(BTPASS);
            uart_puts("): ");
            hc06_setpin(buff,BUFFSIZE);
            uart_puts(buff);
            uart_puts("\r\n");
            timer_delay1s(test,1);
            break;
        }
    }
    uart_puts("timeout.\n");
}
```



```
-----*/
```

Testing Base Kit (202425s1).

basetest.c

```
/*-----*/
-----*/
/* override default tick values */
#define TIMER_TICK_LEN TIMER_VAL50MS
#define TIMER_TICK_CNT TIMER_LOOP_1S
/*-----*/
-----*/
#include "my1stc51.h"
#include "timer_tick.h"
#include "led7seg.h"
/*-----*/
-----*/
void main(void) {
    unsigned char loop, mask, seg7[] = { _7SEGNUM_CC_ };
    P1MODE1(); // better pullup current
    loop = 0; mask = (!P2_7)?0xff:0x00;
    P1 = seg7[loop] ^ mask;
    timer_init();
    timer_tick_exec();
    while (1) {
        P2_0 = !P3_7;
        P2_1 = !P3_6;
        P2_2 = !P3_5;
        P2_3 = !P3_4;
        if (timer_ticked()) {
            loop++; if (loop==10) loop = 0;
            mask = (!P2_7)?0xff:0x00;
            P1 = seg7[loop] ^ mask;
            timer_tick00();
        }
    }
}
/*-----*/
-----*/
```

Code: relay

Testing basic relay.

relay.c

```

/*-----*/
-----*/
#include "timer.h"
#include "uart.h"
/*-----*/
-----*/
MY1SBIT(DRIVE, PIN20);
MY1SBIT(INPUT, PIN10);
/*-----*/
-----*/
void main(void) {
    unsigned char wait;
    timer_init();
    uart_init();
    uart_puts("\nTESTING RELAY\n");
    DRIVE = 1; /* active low */
    INPUT = 1;
    while(1) {
        if (INPUT==0) {
            uart_puts("-- Switch ON... ");
            DRIVE = 0;
            wait = 3*TIMER_LOOP_1S;
            do { timer_wait(TIMER_VAL50MS); } while (--wait);
            uart_puts("OFF.\n");
            DRIVE = 1;
            while (!INPUT);
        }
    }
}
/*-----*/
-----*/

```

Code: gtuc51

Test code for the old GTUC51B001 development board.

gtuc51.c

```

/*-----*/
-----*/
/**
 * Demo program for gtuc51 (with io board)
 **/
/*-----*/
-----*/

```

```
#include "adc0831.h"
#include "keypad_922.h"
#include "textlcd.h"
#include "utils_float.h"
/*-----*/
-----*/
/**
 * Switch & LED Interface for gtuc51 i/o board
 * - multiplexed (dual/purpose)
 * - require jumper link settings!
 */
/** SW0, SW1 => P3.3, P3.2 - LAYOUT ERROR */
__sbit __at (0xB3) SW0;
__sbit __at (0xB2) SW1;
/** LED{0-3} => P3.4-P3.7 */
__sbit __at (0xB4) LED0;
__sbit __at (0xB5) LED1;
__sbit __at (0xB6) LED2;
__sbit __at (0xB7) LED3;
/** LED{RX,TX} => P3.1, P3.0 - LAYOUT ERROR */
__sbit __at (0xB1) LEDRX;
__sbit __at (0xB0) LEDTX;
/** alias LEDX=-2 and LEDY=-1 (LEFT OF LED0) */
__sbit __at (0xB1) LEDX;
__sbit __at (0xB0) LEDY;
/*-----*/
-----*/
char display[LCD_MAX_CHAR];
unsigned char lcdi, loop;
float value;
keybyte_t keyin;
adcbyte_t check;
__bit adc, adcgo, left, demo;
/*-----*/
-----*/
#define DEMO_IO 1
#define DEMO_ADC 0
/*-----*/
-----*/
#define LOOP_COUNT 20
/*-----*/
-----*/
/* interrupt service routine for timer0 */
void timer_blink(void) __interrupt TF0_VECTOR {
    TR0 = 0; loop--;
    P1 = ~P1;
    if (loop==0) {
        if (!left) {
            loop = LED0; LED0 = LED1; LED1 = LED2; LED2 = LED3;
            LED3 = LEDX; LEDX = LEDY; LEDY = loop;
        }
    }
}
```

```

    }
    else {
        loop = LED3; LED3 = LED2; LED2 = LED1; LED1 = LED0;
        LED0 = LEDY; LEDY = LEDX; LEDX = loop;
    }
    loop = LOOP_COUNT;
}
TH0 = 0x4B; TL0 = 0xFD; TR0 = 1; /** 50ms */
}
/*-----*/
-----*/
/* interrupt service routine for timer1 */
void timer_goadc(void) __interrupt TF1_VECTOR {
    TR1 = 0; TH1 = 0x4B; TL1 = 0xFD;
    if (loop>0) {
        TR1 = 1; /** 50ms */
        loop--;
    }
    else {
        loop = LOOP_COUNT;
        adcgo = adc;
    }
}
/*-----*/
-----*/
/* interrupt service routine for int1 */
void check_switch0(void) __interrupt IE1_VECTOR {
    left = 0;
    if (lcdi<LCD_MAX_CHAR) {
        lcd_data(0x30);
        lcdi++;
    }
}
/*-----*/
-----*/
/* interrupt service routine for int0 */
void check_switch1(void) __interrupt IE0_VECTOR {
    left = 1;
    if (lcdi<LCD_MAX_CHAR) {
        lcd_data(0x31);
        lcdi++;
    }
}
/*-----*/
-----*/
/* main function */
void main(void) {
    /** initalize stuffs */
    demo = DEMO_IO; /** default... just in case */
    TMOD = 0x11; P1 = 0xFF; P3 = 0xFF;
    lcd_init();
}

```

```
lcd_goto_line1();
lcd_puts("8051 Select Demo");
lcd_goto_line2();
lcd_puts("[SW0]IO [SW1]ADC");
/* wait for user key press */
while (1) {
    if (!SW0) {
        demo = DEMO_IO; /* demo switch, led, keypad and P1 */
        while(!SW0); /** wait until the user press & let go */
        break;
    }
    else if (!SW1) {
        demo = DEMO_ADC; /* demo adc */
        while(!SW1);
        break;
    }
}
/* select! */
if (demo==DEMO_IO) {
    lcd_goto_line1();
    lcd_puts("MY18051 I/O DEMO");
    lcd_goto_line2();
    lcd_puts("                ");
    lcd_goto_line2();
    /** set timer 0 overflow every 50ms - with interrupt handler */
    loop = LOOP_COUNT; lcdi = 0; left = 0;
    P1 = 0xAA; LED0 = 0; IT0 = 1; IT1 = 1;
    EA = 1; ET0 = 1; EX0 = 1; EX1 = 1;
    TH0 = 0x4B; TL0 = 0xFD; TR0 = 1;
    /** main loop */
    while (1) {
        keyin = key_wait_922();
        if (keyin<10&&lcdi<LCD_MAX_CHAR) { /** numeric key! */
            lcd_data(keyin+0x30);
            lcdi++;
        }
        else if(keyin==0x0F) { /** '#' key! */
            lcd_goto_line2();
            lcd_puts("HASHED!                ");
            lcd_goto_line2();
            lcdi = LCD_MAX_CHAR;
        }
        else if(keyin==0x0E) { /** '*' key! */
            lcd_goto_line2();
            lcd_puts("                ");
            lcd_goto_line2();
            lcdi = 0;
        }
    }
}
```


Last update: 2024/11/11
11:50

dev8051:code8051 <http://azman.unimap.edu.my/dokuwiki/doku.php?id=dev8051:code8051&rev=1731297017>

From:

<http://azman.unimap.edu.my/dokuwiki/> - **Azman @UniMAP**

Permanent link:

<http://azman.unimap.edu.my/dokuwiki/doku.php?id=dev8051:code8051&rev=1731297017>

Last update: **2024/11/11 11:50**

